

DESIGNED FOR VICTORY, BUILT FOR

DOMINANCE

USER MANUAL

CS24A/P

WWW. AOC.COM@2025 AOC ALL RIGHTS RESERVED

VERSION: A01

Safety	1
National Conventions	1
Power	2
Installation	3
Cleaning	4
Other	5
Setup	6
Contents in Box	6
Setup Stand & Base	7
Adjusting the monitor	8
Connecting the Monitor	9
Wall Mounting	10
Adaptive-Sync function	12
NVIDIA® G-SYNC® Compatible function	13
HDR	14
Adjusting	15
Hotkeys	
Quick Switch	
Description of Magnetic Zone Range and Mounting Angles for the Projection Lamp	17
Setting Up Counter-Strike Light FX Sync Feature	
OSD Key Guide (Menu)	20
OSD Setting	22
Game Setting	23
Luminance	25
PIP Setting	26
Color Setup	27
Audio	28
Light FX	29
Extra	30
OSD Setup	31
LED Indicator	32
Troubleshoot	33
Specification	34
General Specification	34
Preset Display Modes	
Pin Assignments	38
Plug and Play	39

Safety

National Conventions

The following subsections describe notational conventions used in this document.

Notes, Cautions, and Warnings

Throughout this guide, blocks of text may be accompanied by an icon and printed in bold type or in italic type. These blocks are notes, cautions, and warnings, and they are used as follows:



NOTE: A NOTE indicates important information that helps you make better use of your computer system.



CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



WARNING: A WARNING indicates the potential for bodily harm and tells you how to avoid the problem. Some warnings may appear in alternate formats and may be unaccompanied by an icon. In such cases, the specific presentation of the warning is mandated by regulatory authority.

Power

 \bigwedge The monitor should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.

 Λ The monitor is equipped with a three-pronged grounded plug, a plug with a third (grounding) pin. This plug will fit only into a grounded power outlet as a safety feature. If your outlet does not accommodate the three-wire plug, have an electrician install the correct outlet, or use an adapter to ground the appliance safely. Do not defeat the safety purpose of the grounded plug.

 Λ Unplug the unit during a lightning storm or when it will not be used for long periods of time. This will protect the monitor from damage due to power surges.



⚠ Do not overload power strips and extension cords. Overloading can result in fire or electric shock.

To ensure satisfactory operation, use the monitor only with UL listed computers which have appropriate configured receptacles marked between 100-240V AC, Min. 5A.



The wall socket shall be installed near the equipment and shall be easily accessible.

Installation

🛕 Do not place the monitor on an unstable cart, stand, tripod, bracket, or table. If the monitor falls, it can injure a person and cause serious damage to this product. Use only a cart, stand, tripod, bracket, or table recommended by the manufacturer or sold with this product. Follow the manufacturer's instructions when installing the product and use mounting accessories recommended by the manufacturer. A product and cart combination should be moved with care.

A Never push any object into the slot on the monitor cabinet. It could damage circuit parts causing a fire or electric shock. Never spill liquids on the monitor.

Do not place the front of the product on the floor.


lack If you mount the monitor on a wall or shelf, use a mounting kit approved by the manufacturer and follow the kit instructions.

1 Leave some space around the monitor as shown below. Otherwise, air-circulation may be inadequate hence overheating may cause a fire or damage to the monitor.

1 To avoid potential damage, for example the panel peeling from the bezel, ensure that the monitor does not tilt downward by more than -5 degrees. If the -5 degree downward tilt angle maximum is exceeded, the monitor damage will not be covered under warranty.

See below the recommended ventilation areas around the monitor when the monitor is installed on the wall or on the stand:


Installed with stand




Cleaning

Clean the cabinet regularly with a water-dampened, soft cloth.

• When cleaning use a soft cotton or microfiber cloth. The cloth should be damp and almost dry, do not allow liquid into the case.







Please disconnect the power cord before cleaning the product.

Other

If the product is emitting a strange smell, sound or smoke, disconnect the power plug IMMEDIATELY and contact a Service Center.



Make sure that the ventilating openings are not blocked by a table or curtain.




not engage the LCD monitor in severe vibration or high impact conditions during operation.



1 Do not knock or drop the monitor during operation or transportation.

Setup

Contents in Box




Not all signal cables will be provided for all countries and regions. Please check with the local dealer or AOC branch office for confirmation.


Setup Stand & Base

Please setup or remove the base following the steps as below.

Setup:



Remove:




NOTE: Display design may differ from those illustrated.

Adjusting the monitor

For optimal viewing it is recommended to look at the full face of the monitor, then adjust the monitor's angle to your own preference.

Hold the stand so you will not topple the monitor when you change the monitor's angle.

You are able to adjust the monitor as below:






Do not touch the LCD screen when you change the angle. Touching the LCD screen may cause damage.

Warning:

- 1. To avoid potential screen damage, such as panel peeling, ensure that the monitor does not tilt downward by more than -5 degrees.
- 2. Do not press the screen while adjusting the angle of the monitor. Grasp only the bezel.

Connecting the Monitor

Cable Connections In Back of Monitor.



- 1. Power
- 2. HDMI1
- 3. HDMI2
- 4. DisplayPort
- 5. Earphone
- 6. Quick Switch port
- 7. USB3.2 Genl upstream
- 8. USB3.2 Gen1 downstream + fast charging (Yellow) CS Light FX Sync lighting port (Black)
- 9. USB3.2 Gen1 downstream
- 10. USB3.2 Gen1 downstream

Connect to PC


- 1. Connect the power cord to the back of the display firmly.
- 2. Turn off your computer and unplug its power cable.
- 3. Connect the display signal cable to the video connector on your computer.
- 4. Plug the power cord of your computer and your display into a nearby outlet.
- 5. Turn on your computer and display.

If your monitor displays an image, installation is complete. If it does not display an image, please refer Troubleshooting.

To protect equipment, always turn off the PC and LCD monitor before connecting.

Wall Mounting


Preparing to Install An Optional Wall Mounting Arm.




This monitor can be attached to a wall mounting arm you purchase separately. Disconnect power before this procedure. Follow these steps:

- 1. Remove the base.
- 2. Follow the manufacturer's instructions to assemble the wall mounting arm.
- 3. Place the wall mounting arm onto the back of the monitor. Line up the holes of the arm with the holes in the back of the monitor.
- 4. Reconnect the cables. Refer to the user's manual that came with the optional wall mounting arm for instructions on attaching it to the wall.


Wall hanger:



Specification of wall hanger screws: M4*(12+X)mm, (X=Thickness of Wall mount bracket)



Noted: VESA mounting screw holes are not available for all models, please check with the dealer or official department of AOC. Always contact manufacturer for wall-mount installation.



* Display design may differ from those illustrated.

Warning:

- 1. To avoid potential screen damage, such as panel peeling, ensure that the monitor does not tilt downward by more than -5 degrees.
- 2. Do not press the screen while adjusting the angle of the monitor. Grasp only the bezel.

Adaptive-Sync function

- 1. Adaptive-Sync function works with DisplayPort/HDMI
- 2. Compatible Graphics Card: Recommended list is as below, also could be checked by visiting <u>www.AMD.</u> <u>com</u>

Graphics Cards

- Radeon™ RX Vega series
- Radeon™ RX 500 series
- Radeon™ RX 400 series
- Radeon™ R9/R7 300 series (R9 370/X, R7 370/X, R7 265 except)
- Radeon™ Pro Duo (2016)
- Radeon™ R9 Nano series
- Radeon™ R9 Fury series
- Radeon™ R9/R7 200 series (R9 270/X, R9 280/X except)

Processors

- AMD Ryzen™ 7 2700U
- AMD Ryzen™ 5 2500U
- AMD Ryzen™ 5 2400G
- AMD Ryzen™ 3 2300U
- AMD Ryzen™ 3 2200G
- · AMD PRO A12-9800
- AMD PRO A12-9800E
- · AMD PRO A10-9700
- · AMD PRO A10-9700E
- · AMD PRO A8-9600
- · AMD PRO A6-9500
- · AMD PRO A6-9500E
- · AMD PRO A12-8870
- AMD PRO A12-8870E
- AMD PRO A10-8770
- AMD PRO A10-8770E
- AMD PRO A10-8750B
- AMD PRO A8-8650B
- · AMD PRO A6-8570
- AMD PRO A6-8570E
- · AMD PRO A4-8350B
- · AMD A10-7890K
- AMD A10-7870K
- AMD A10-7850K
- · AMD A10-7800
- AMD A10-7700K
- AMD A8-7670K
- AMD A8-7650K
- AMD A8-7600
- AMD A6-7400K

.

NVIDIA® G-SYNC® Compatible function

- 1. NVIDIA® G-SYNC® Compatible function is works with DisplayPort.
- 2. To enjoy the perfect gaming experience with G-SYNC, you need to purchase a Separate NVIDIA GPU card that supports G-SYNC.

G-sync system requirements

Desktop computer connected to G-SYNC monitor:

Graphics cards supported: G-SYNC features require NVIDIA GeForce® GTX 650 Ti BOOST or higher graphics cards.

Driver: R340.52 or later Operating system:

Windows 11

Windows 10

Windows 8.1

Windows 7

System requirements: DisplayPort 1.2 of the GPU must be supported.

Notebook computer connected to G-SYNC monitor:

Supported graphics cards: NVIDIA GeForce® GTX 980M, GTX 970M, GTX 965M GPU or higher graphics cards

Driver: R340.52 or higher

Operating system:

Windows 11

Windows 10

Windows 8.1

Windows 7

System requirements: DisplayPort 1.2 driven directly from the GPU must be supported.

For more information about NVIDIA G-Sync, please visit: https://www.nvidia.com/en-us/support


HDR

It is compatible with input signals in HDR10 format.

The display may automatically activate the HDR function if the player and content are compatible. Please contact the device manufacturer and the content provider for information on the compatibility of your device and content. Please select "OFF" for the HDR function when you have no need for automatical activation function.


Note:

- 1. No special setting is needed for the DisplayPort/HDMI interface in WIN10 versions lower (older) than V1703.
- 2. Only the HDMI interface is available and the DisplayPort interface cannot function in WIN10 version V1703.
- 3. Display Setting:
- a. The display resolution is set to 1920*1080.
- b. After entering an application, the best HDR effect can be achieved when the resolution is changed to 1920*1080 (if available).



Adjusting

Hotkeys



1	Source/Up
2	Down
3	Game Mode/Left
4	Right
5	Power/Menu/Enter

Power/Menu/Enter

Press the Power button to turn on the monitor.

When there is no OSD, Press to display the OSD or confirm the selection. Press about 2 seconds to turn off the monitor.


Game Mode/Left

When there is no OSD, press "Left" key to open game mode function, then press "Left" or "Right" key to select game mode (CS, FPS1, FPS2, FPS3, RTS, Racing, Gamer 2 or Gamer 3) basing on the different game types.

Source/Up

When the OSD is closed, press Source/Auto/Up button will be Source hot key function.

Quick Switch



∢:

When there is no OSD, press the ◀ button to open game mode function, then press ◀ or ▶ key to select game mode (CS, FPS1, FPS2, FPS3, RTS, RTS, Racing, Gamer 2 or Gamer 3) basing on the different game types.

▶:

When there is no OSD, press "Right" key to active Light FX function.

When there is no OSD, Press to display the OSD or confirm the selection.

A:

When the OSD is closed, press ▲ button will be Source hot key function.

▼:

When there is no OSD, press Dial Point button to show / hide Dial Point.

1:

Press the 1 button to select CS mode

2:

Press the 2 button to select Gamer 2 mode

3:


Press the 3 button to select Gamer 3 mode




Press to exit OSD.

Description of Magnetic Zone Range and Mounting Angles for the Projection Lamp

1. The magnetic attraction area of the monitor bracket and projection lamp is shown in the following figure.




The diagonal lines in the figure represent the areas where the display bracket can provide magnetic attraction



The symbols $\mathbf{\dot{U}}$ in the figure represent the areas where the projection lamp can provide magnetic attraction

2.The diagram illustrates the magnetic attachment positions of the CS24A/P projection lamp on the display bracket. From left to right, the positions are: TOP 90°, TOP 45°, TOP 0°, SIDE 90°, and SIDE 45° (angles represent the inclination between the lamp body and the horizontal desktop).



Setting Up Counter-Strike Light FX Sync Feature

This product supports the Counter-Strike Light FX Sync feature.

By connecting the USB upstream cable, installing and running G-Menu, the Light FX gaming ambient lighting can interact with in-game events in Counter-Strike 2.

Setting steps:

- 1. Access the link: https://au.aoc.com/index/explore/route/softwares to download and install the latest version of **G-Menu**.
- 2. Ensure the "DDC/CI" option in the monitor's OSD menu is set to "Yes" (default factory setting).
- 3. Connect the monitor's **USB-B upstream port** to the computer's **USB-A port** using the included USB cable.
- 4. Launch **G-Menu**.

G-Menu Configuration Steps:

Step 1: Select "Monitor" - G-Menu will automatically scan for the monitor.



Step 2: Select "Game".

Step 3: Click the **Counter-Strike 2 icon**. When the icon lights up, the **CS Light FX Sync** feature will be activated.



Step 4: Adjust the "BRIGHTNESS" slider to set the intensity of the Light FX ambient lighting.



After setting, it can be minimized G-Menu Window.

Launch Counter-Strike2, and the CS Light FX Sync lighting will synchronize with in-game events. Example of CS Light FX Sync lighting effects synchronized with Counter-Strike2 in-game events:

Event	Light Color	Light effect	
Round Prepare(FreezeTime)	Blue	continuous	
Round start	Blue	continuous	
Bomb on hand (even not switched out) & planting	Yellow	continuous	
Planted (to 10s before explosion)	Yellow	Blink	
Planted (last 10s)	red	Blink	
Bomb explode	Green	Blink to dim	
Bomb defused	Green	Continuous to dim	
Flashed (doesn't matter full flash or half flash)	White	continuous	
Low health (when health bar turns red, I believe is when health <25, RD please help check)	Blue	blink	
Die	/	dim	
After death	/	dim	
Counter Strike 2 Game Modes	Support CS lighting FX		
Competitive Mode	Yes		
Wingman Mode	Yes		
Casual Mode	Yes		
DeathMatch Mode	No		
Arms Race Mode	No		

OSD Key Guide (Menu)



Enter: Use Enter key to enter the next OSD level Move: Use Left / Up / Down key to move OSD selection

Exit: Use Right key to exit OSD



Enter: Use Enter key to enter the next OSD level

Move: Use Right / Up / Down key to move OSD selection

Exit: Use Left key to exit OSD



Enter: Use Enter key to enter the next OSD level Move: Use Up / Down key to move OSD selection

Exit: Use Left key to exit OSD



Move: Use Left / Right / Up / Down Key to move OSD selection



Exit: Use Left key to exit OSD to previous OSD level Enter: Use Right key to enter next OSD level Select: Use Up / Down key to move OSD selection



Enter: Use Enter key to apply the OSD setting and back to previous OSD level Select: Use Down key to adjust OSD setting




Select : Use Up / Down key to adjust OSD setting



Enter: Use Enter key to exit OSD to previous OSD level Select: Use Left / Right key to adjust OSD setting

OSD Setting

Basic and simple instruction on the control keys.



- 1). Press the MENU-button to activate the OSD window.
- 2). Follow Key Guide to move or select (adjust) OSD settings
- 3). OSD Lock/Unlock Function: To lock or unlock the OSD, press and hold the Down-button for 10s while OSD function is not active.

Notes:

- 1). If the product has only one signal input, the item of "Input Select" is disable to adjust.
- 2). ECO modes (except Standard mode) and DCR, for these two states that only one state can exist.

Game Setting



V		V	
		Off	No optimization by Game Mode.
		CS	For playing CS game. CS mode tuning. Specifically designed for control CS2 Born. Adjust and enhance visual clarity, image sharpness, and response speed.
		FPS1	
		FPS2	For playing FPS1/FPS2/FPS3 (First Person Shooters) games. Improves dark theme black level details.
	Game Mode	FPS3	
		RTS	For playing RTS (Real Time Strategy). Improves the image quality.
Letters New		Racing	For playing Racing games, Provides fastest response time and high color saturation.
		Gamer 2	User's preference settings saved as Gamer 2.
Game Setting		Gamer 3	User's preference settings saved as Gamer 3.
Game Setting	Image Ratio	Full(16:9) / 1:1(16:9) / Full(Square) / 1:1(Square) / Aspect	Select image ratio for display.
	Shadow Control	0-20	Shadow Control Default is 0, then end-user can adjust from 0 to 20 or 0 to increase contrast for clear picture. 1. If picture is too dark to be saw the detail clearly, adjusting from 0 to 20 for clear picture. 2. If picture is too white to be saw the detail clearly, adjusting from 20 to 0 for clear picture.
	Game Color	0-20	Game Color will provide 0-20 level for adjusting saturation to get better picture.

Sniper Scope	Off/1.0/1.5/2.0	Zoom in locally to make it easier to target when shooting.
MBR+	0-20	Adjust the Motion Blur Reduction.
MBR Sync	On / Off	Disable or Enable MBR Sync (Motion Blur Remove). Note: The MBR function can be adjusted when Adaptive- Sync/G-SYNC is turned off, and the refresh rate ≥75Hz.
Adaptive-Sync	On / Off	Disable or Enable Adaptive-Sync. Note: When the HDMI signal is input, the Adaptive-Sync option will be displayed for adjustment. Disable or Enable G-SYNC.
G-SYNC	On / Off	Note: When the DisplayPort signal is input, the G-SYNC option will be displayed for adjustment.
Overdrive	0-21	Adjust the response time.
Low Input lag	On / Off	Turn off frame buffer to decrease input lag.
QuickSwitch LED	On / Off	Disable or Enable QuickSwitch LED
Frame Counter	Off / Right-Up / Right-Down / Left-Down / Left- Up	Display V frequency on the corner selected. (Frame counter feature only works with AMD graphic card.)
Dial Point	Off / Dynamic / On	The "Dial Point" function places an aiming indicator in the center of screen for helping gamers to play First Person Shooter (FPS1/FPS2/FPS3) games with an accurate and precise aiming. Disable or Enable DialPoint. After the monitor is turned on/off, the DialPoint will automatically turn off. When the DialPoint is enabled, the crosshair will be placed in the center of the screen, helping players to accurately aim while playing first person shooter games.
OverClock	On / Off	Disable or Enable Over Clock
HDMII	Console/DVD / PC	When connecting a game console or DVD player, please set HDMII to Console/DVD. When connecting to a desktop/laptop computer,
HDMI2	Console/DVD /	please set HDMII to PC. When connecting a game console or DVD player, please set HDMI2 to Console/DVD. When connecting to a desktop/laptop computer,
	FC	please set HDMI1 to PC.

Note:

- 1. When "HDR Mode" under "Brightness" is set to non-off, "Shadow Control" and "Game Color" can't be adjusted.
- 2. When "HDR" under "Brightness" is set to non-off, "Game Mode", "Shadow Control", "Game Color", "MBR+", "MBR Sync" and "Boost" under "Overdrive" can't be adjusted or selected.

 3. When the "Color Gamut" under "Color Setup" is set to sRGB, the items "Shadow Control", "Game Color", "MBR", "MBR Sync" and "Boost" under "Overdrive" can't be adjusted or selected..

Luminance



	Contrast	0-100	Contrast from Digital-register.
	Brightness	0-100	Backlight Adjustment.
	Dark Boost	Off / Level 1 / Level 2 / Level 3	Enhance the screen details in the dark or bright area to adjust the brightness in the bright area and ensure that it is not oversaturated.
	Sharpness	0-100	Sharpness Adjustment.
		Standard	Standard Mode
		Text	Text Mode
		Internet	Internet Mode
	Eco mode	Game	Game Mode
	Ecomode	Movie	Movie Mode
		Sports	Sports Mode
		Reading	Reading Mode
		Uniformity	Uniformity Mode
	Gamma	2.0	Adjust to Gamma 2.0
Sign Comp		2.2	Adjust to Gamma 2.2
Luminance		2.4	Adjust to Gamma 2.4
	DCR	Off/On	Disable/ Enable dynamic contrast ratio
	HDR	Off / DisplayHDR / HDR Picture / HDR Movie / HDR Game	Set the HDR profile according to your usage requirements. Note: When HDR content is detected, the HDR option will be displayed for adjustment.
	HDR Mode	Off / HDR Picture / HDR Movie / HDR Game	Optimized for the color and contrast of the picture, which simulates HDR effect. Note: When HDR content is not detected, the HDR mode option will be displayed for adjustment.
		Off	
	Local	Low	Disable or Chasse Level Dimmins
	Dimming	Medium	Disable or Choose Local Dimming.
		Strong	

Note:

1. When "HDR Mode" under "Brightness" is set to non-off, "Contrast", "Eco Mode", "Dark Boost" and "Gamma" can't be adjusted.

- 2. When "HDR" is set to "DisplayHDR", except for "HDR" and "Regional Dimming", other items under "Brightness" cannot be adjusted.
- 3. When "HDR" is set to "HDR Picture", "HDR Movie", or "HDR Game", "Sharpness", "Eco Mode", and "Gamma", "DCR" can't be adjusted.
- 3. When "Color Gamut" under "Color Setup" is set to sRGB, "Contrast", "Eco Mode", "Dark Boost", "HDR Mode" and "Gamma" can't be adjusted.

PIP Setting



	PIP	Off/PIP/PBP	Disable or Enable PIP or PBP.
	Main Source		Select main screen source.
	Sub Source		Select sub screen source.
	Size	Small / Middle / Large	Select screen size.
PIP Setting	Position	Right-Up / Right-Down / Left-Down / Left-Up	Set the screen location.
	Audio	Off/On	Select the audio output for the primary or secondary screen.
	Swap	Off/On	Convert screen source.


Note:

- 1). When "HDR" under "Brightness" is set to non-closed state, all items under "PIP" are not adjustable.
- 2). The OSD menu color adjustment is only valid for the main screen, so the main screen and the sub screen may have different colors.
- 3). When PBP/PIP is enabled, the compatibility of the main screen/sub-screen input source is shown in the following table:

PIP/PBP		Main source		
		HDMII	HDMI2	DP
	HDMII	V	V	V
Sub sources	HDMI2	V	V	V
	DisplayPort	V	V	V

Color Setup





Note:

When "HDR Mode" or "HDR" under "Luminance" is set to "non-off", all items under "Color Setup" cannot be adjusted.

When the "Color Gamut" under "Color Setup" is set to sRGB, all items under "Color Setup" cannot be adjusted.

Audio



	Volume	0-100	Adjust volume setting
Audio			


Light FX



	Light FX	Off / Low / Medium / Strong	Select the intensity of Light FX.	
i i i i i i i i i i i i i i i i i i i	Light FX Mode	CS / Audio1 / Audio2 / Static / Dark Point Sweep / Gradient Shift / Spread Fill / Drip Fill / Spreading Drip Fill / Breathing / Light Point Sweep / Zoom / Rainbow / Wave /Flashing / Demo	Select Light FX Mode	
Light FX	Pattern	Red / Green / Blue / Rainbow / User Define	Select Light FX Pattern	
LIGHT FX	Foreground R	0-100		
	Foreground G		User can adjust Light FX foreground color, when Pattern setting to user define	
	Foreground B			
	Background R			
	Background G	0-100	User can adjust Light FX background color, when Pattern setting to user define	
	Background B			


Extra





OSD Setup





LED Indicator

Status	LED Color
Full Power Mode	White
Active-off Mode	Orange

Troubleshoot

Problem & Question	Possible Solutions
Power LED Is Not On	Make sure the power button is ON and the Power Cord is properly
No Images On The Screen	 Is the power cord connected properly? Check the power cord connection and power supply. Is the video cable connected correctly?? (Connected using the VGA cable) Check the VGA cable connection. (Connected using the HDMI cable) Check the HDMI cable connection. (Connected using the DisplayPort cable) Check the DisplayPort cable connection. *VGA/HDMI/DisplayPort input is not available on every model. If the power is on, reboot the computer to see the initial screen (the login screen.) If the initial screen (the login screen) appears, boot the computer in the applicable mode (the safe mode for Windows 7/8/10) and then change the frequency of the video card. (Refer to the Setting the Optimal Resolution) If the initial screen (the login screen) does not appear, contact the Service Center or your dealer. Can you see "Input Not Supported" on the screen? You can see this message when the signal from the video card exceeds the maximum resolution and frequency that the monitor can handle properly. Adjust the maximum resolution and frequency that the monitor can handle properly.
Picture Is Fuzzy & Has Ghosting Shadowing Problem	 Make sure the AOC Monitor Drivers are installed. Adjust the Contrast and Brightness Controls. Press hot-key (AUTO) to auto-adjust. Make sure you are not using an extension cable or switch box. We recommend plugging the monitor directly to the video card output connector on the back.
Picture Bounces, Flickers Or Wave Pattern Appears In The Picture	Move electrical devices that may cause electrical interference as far away from the monitor as possible. Use the maximum refresh rate your monitor is capable of at the resolution you are using.
Monitor Is Stuck In Active Off-Mode	The Computer Power Switch should be in the ON position. The Computer Video Card should be snugly fitted in its slot. Make sure the monitor's video cable is properly connected to the computer. Inspect the monitor's video cable and make sure no pin is bent. Make sure your computer is operational by hitting the CAPS LOCK key on the keyboard while observing the CAPS LOCK LED. The LED should either turn ON or OFF after hitting the CAPS LOCK key.
Missing One Of The Primary Colors (RED, GREEN, or BLUE)	Inspect the monitor's video cable and make sure that no pin is damaged. Make sure the monitor's video cable is properly connected to the computer.
Screen Image Is Not Centered Or Sized Properly	Adjust H-Position and V-Position or press hot-key (AUTO).
Picture Has Color Defects (White Does Not Look White)	Adjust RGB color or select desired color temperature.
Horizontal Or Vertical Disturbances On the screen	Use Windows 7/8/10 shut-down mode to adjust CLOCK and FOCUS. Press hot-key (AUTO) to auto-adjust.
Regulation & Service	Please refer to Regulation & Service Information at www.aoc.com (to find the model you purchase in your country and to find Regulation & Service Information in Support page.

Specification

General Specification

	Model name	CS24A/P			
Panel	Driving system	TFT Color LCD			
	Viewable Image Size	61.3 cm diagonal			
	Pixel pitch	0.279mm(H) x 0.276mm(V)			
	Display Color	16.7M Colors			
	Horizontal scan range 30k~510kHz				
	Horizontal scan Size(Maximum)	535.68mm			
	Vertical scan range	60~610Hz			
	Vertical Scan Size(Maximum)	298.08mm			
	Optimal preset resolution	1920x1080@60Hz			
Others	Max resolution	1920x1080@610Hz*			
Ctricis	Plug & Play	VESA DDC2B/CI			
	Power Source	100-240V~ 50/60Hz 1.5A			
		Typical (default brightness and		30W	
	Power Consumption	contrast)			
		Max. (Brightness = 100, contrast =100)		≤107W	
		Standby mode	≤0.5W		
Physical	Connector Type	HDMIx2/DisplayPort/USBx3/CS Light FX Sync lighting p /USB UP/Earphone		X Sync lighting port	
Characteristics	Signal Cable Type	Detachable			
	Ta ma in a marki i ma	Operating	0°C ~ 40°C		
Environmental	Temperature	Non-Operating	-25°C ~ 55°C		
	I I complete o	Operating	10% ~ 85% (non-condensing)		
	Humidity	Non-Operating	5% ~ 93% (non-condensing)		
	Altituda	Operating	0m ~ 5000m (0ft ~ 16404ft)		
	Altitude	Non-Operating	0m ~ 12192m (0ft ~ 40000ft)		

Note:

- 1). Overclocking is achieved when resolution is at 1920x1080@610Hz. If any display error occurs during overclocking, please adjust the refresh rate to 300Hz.
- 2). To experience FHD 600Hz/610Hz, please upgrade your operating system to Windows 11 and update to the latest version. NVIDIA® It is recommended to use the DisplayPort interface for graphics cards, AMD®It is recommended to use HDMI interface for graphics cards.
- 3). The maximum refresh rate supported by a graphics card is related to the GPU, graphics card driver, and operating system, and some graphics cards may not be able to select 600Hz/610Hz. After testing, the compatibility status of some graphics cards with FHD 600Hz/610Hz is shown in the table below (Windows 11 operating system+latest graphics card driver).

Graphics chip	Graphics card	HDMIport	DisplayPort port
	Gigabyte RX 7900XTX	Support FHD 600Hz / 610Hz	Support FHD 600Hz / 610Hz
AMD	Sapphire RX 7700 XT	Support FHD 600Hz / 610Hz	Support FHD 600Hz / 610Hz
AMD	AMD RX 6950 XT	Support FHD 600Hz / 610Hz	Support FHD 610Hz
	ASUS RX 6750 XT	Support FHD 600Hz / 610Hz	Support FHD 610Hz
	NVIDIA RTX 4090	Supports up to FHD 540Hz	Support FHD 600Hz / 610Hz
	Gigabyte RTX 4080	Supports up to FHD 540Hz	Support FHD 600Hz / 610Hz
	MSI RTX 4070	Supports up to FHD 540Hz	Support FHD 600Hz / 610Hz
NVIDIA	ASUS RTX 4060 Ti	Supports up to FHD 540Hz	Support FHD 600Hz / 610Hz
	MSI RTX 4080 S	Supports up to FHD 540Hz	Support FHD 600Hz / 610Hz
	ASUS RTX 3070	Supports up to FHD 540Hz	Support FHD 600Hz / 610Hz
	NVIDIA RTX 5080	Support FHD 600Hz / 610Hz	Support FHD 600Hz / 610Hz

^{4).} To achieve FHD 480Hz 8-bit (RBB/YCbCr 4:4:4 format) and above resolution, a graphics card that supports DSC must be used for the DisplayPort 1.4 signal input. Please consult the graphics card manufacturer for DSC support.

Preset Display Modes

PC Resolution

Image Ratio Signal Version	Full(16:9) 1:1(16:9)		Full(Square) 1:1(Square) Aspect		
Resolution State	HDMI2.1	DisplayPort1.4	HDMI2.1	DisplayPort1.4	
640x480/60Hz	\checkmark	√	\checkmark	√	
640x480/67Hz	\checkmark	√	$\sqrt{}$	√	
640x480/72Hz	√	√	√	√	
640x480/75Hz	√	√	$\sqrt{}$	√	
640x480/100Hz	√	√	$\sqrt{}$	√	
640x480/120Hz	√	√	√	√	
720x400/70Hz	√	√	√	√	
800x600/56Hz	√	√	√	√	
800x600/60Hz	√	√	√	√	
800x600/72Hz	√	√	√	√	
800x600/75Hz	\checkmark	√	\checkmark	√	
800x600/100Hz	\checkmark	√	\checkmark	√	
800x600/120Hz	\checkmark	√	$\sqrt{}$	√	
832x624/75Hz	√	√	√	√	
1024x768/60Hz	√	√	√	√	
1024x768/70Hz	√	√	√	√	
1024x768/75Hz	√	√	√	√	
1024x768/100Hz	√	√	√	√	
1024x768/600Hz			√	√	
1024x768/610Hz			\checkmark	√	
1280x960/60Hz			\checkmark	√	
1280x960/500Hz	\checkmark	√			
1280x960/600Hz	\checkmark	√	\checkmark	√	
1280x960/610Hz	\checkmark	√	\checkmark	√	
1280x1024/75Hz	\checkmark	√	$\sqrt{}$	√	
1280x1024/600Hz			\checkmark	√	
1280x1024/610Hz			$\sqrt{}$	√	
1440x1080/600Hz			√	√	
1440x1080/610Hz			$\sqrt{}$	√	
1728x1080/600Hz			\checkmark	√	
1728x1080/610Hz			$\sqrt{}$	√	
1920x1080/60Hz	√	√			
1920x1080/120Hz	\checkmark	√			
1920x1080/144Hz	\checkmark	√			
1920x1080/240Hz	\checkmark	√	\checkmark	√	
1920x1080/360Hz	\checkmark	√			
1920x1080/500Hz	\checkmark	√			
1920x1080/600Hz	\checkmark	√			
1920x1080/610Hz	√	√			


Video Resolution

Image Ratio Signal Version		(16:9) 6:9)	Full(Square) 1:1(Square) Aspect	
Resolution State	HDMI2.1	DisplayPort1.4	HDMI2.1	DisplayPort1.4
640x480p,59.94Hz/60Hz	√	√	√	√
720x480p,59.94Hz/60Hz	\checkmark	√	\checkmark	√
720x576p,50Hz	\checkmark	√	\checkmark	√
1280x720p,50Hz	\checkmark	√	\checkmark	√
1280x720p,59.94Hz/60Hz	\checkmark	√	\checkmark	√
1920x1080i,50Hz	\checkmark	√	\checkmark	√
1920x1080p,50Hz	\checkmark	√	\checkmark	\checkmark
1920x1080i,59.94Hz/60Hz	\checkmark	√	\checkmark	\checkmark
1920x1080p,59.94Hz/60Hz	\checkmark	√	\checkmark	\checkmark
1920x1080p,119.88Hz/120Hz	\checkmark	√	\checkmark	\checkmark
3840x2160p,50Hz			\checkmark	
3840x2160p,59.94Hz/60Hz	\checkmark		\checkmark	
3840x2160p,119.88Hz/120Hz	\checkmark		\checkmark	

Note:


- 1. To achieve ideal image quality, please refer to the table above to set the resolution of the input signal source. The set resolution varies depending on the signal output device: for gaming consoles, it is recommended to refer to "Video Resolution"; PC For games, it is recommended to refer to "PC Resolution".
- 2. To switch the "Image Scale" setting of the monitor, please enter OSD Menu ->"Game Settings" ->"Image Scale" Adjustment.
- 3. To ensure that the above resolutions can function properly, please first check the compatibility of the graphics card. Due to different graphics card strategies, some options may be hidden. Please refer to the actual graphics card support situation.
- 4. According to the VESA standard, there may be a certain error (+/-1Hz) when calculating the refresh rate (field frequency) of different operating systems and graphics cards. In order to improve compatibility, the nominal refresh rate of this product has been rounded off. Please refer to the actual product.

Pin Assignments



19-Pin Color Display Signal Cable

Pin No.	Signal Name	Pin No.	Signal Name	Pin No.	Signal Name
1.	TMDS Data 2+	9.	TMDS Data 0-	17.	DDC/CEC Ground
2.	TMDS Data 2 Shield	10.	TMDS Clock +	18.	+5V Power
3.	TMDS Data 2-	11.	TMDS Clock Shield	19.	Hot Plug Detect
4.	TMDS Data 1+	12.	TMDS Clock-		
5.	TMDS Data 1Shield	13.	CEC		
6.	TMDS Data 1-	14.	Reserved (N.C. on device)		
7.	TMDS Data 0+	15.	SCL		
8.	TMDS Data 0 Shield	16.	SDA		



20-Pin Color Display Signal Cable

Pin No.	Signal Name	Pin No.	Signal Name
1	ML_Lane 3 (n)	11	GND
2	GND	12	ML_Lane 0 (p)
3	ML_Lane 3 (p)	13	CONFIG1
4	ML_Lane 2 (n)	14	CONFIG2
5	GND	15	AUX_CH(p)
6	ML_Lane 2 (p)	16	GND
7	ML_Lane 1 (n)	17	AUX_CH(n)
8	GND	18	Hot Plug Detect
9	ML_Lane 1 (p)	19	Return DP_PWR
10	ML_Lane O (n)	20	DP_PWR

Plug and Play

Plug & Play DDC2B Feature

This monitor is equipped with VESA DDC2B capabilities according to the VESA DDC STANDARD. It allows the monitor to inform the host system of its identity and, depending on the level of DDC used, communicate additional information about its display capabilities.

The DDC2B is a bi-directional data channel based on the I2C protocol. The host can request EDID information over the DDC2B channel.