



Quick Start




Remote Control and AAA Batteries



Power cord



HDMI Cable



RS232 Cable



RS232+RJ45



RJ45 Cable



IR Transducer




Wall mount brackets (4pcs)




Screws (16pcs)

* Differences according to regions.


Display design and accessories may differ from those illustrated above.




1



2



3



AC IN




HDMI



DVI



D-SUB



USB



RS232 IN



RS232 IR OUT



HDMI



DVI





D-SUB



IR IN

4



AOC

46D9115
55D9115



Quick Start

Specifications are subject to change without notice.
2019-8



Q41G78S261560B